

Harness Inspection Checklist

Employee (Print): _____

Inspected By (Print): _____

Signature: _____

Signature: _____

Date: _____

Date: _____

FULL BODY HARNESS INSPECTION

WEBBING	PASS	FAIL	NOTE
Cuts / Burns or Charring			
Abrasions / Broken Fibers / Swelling			
Kinks / Cracks / Holes			
Excessive Wear / Discoloration / Chemical or Physical Exposure			
Loose, Cut or Missing Stitching			
Chest Strap Hook & Loop Have Sufficient Adhesion			
Evidence of Shock Load to Harness			
HARDWARE	PASS	FAIL	NOTE
Cracks / Nicks			
Distorted / Bent			
Moderate to Severe Rust / Corrosion			
Quick Connect Buckles Operate Properly			



NOTES:

FOR MORE INFORMATION CONTACT US:

(800) 451-3077 OR VISIT WWW.RITZSAFETY.COM



SRL Inspection Checklist



Employee (Print): _____ Inspected By (Print): _____

Signature: _____ Signature: _____

Date: _____ Date: _____

LABELS & MARKINGS	PASS	FAIL	NOTE
Are Labels intact & Legible?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Are appropriate ANSI/OSHA/CSA markings visible?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Are inspections current / up-to-date?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Is date of first use documented?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
HARDWARE (BUCKLES & D-RINGS)	PASS	FAIL	NOTE
Is fall indicator tripped?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Is connector free of corrosion/cracks/pitting/deformation?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Does connector latch seat into nose properly?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Does connector spring firmly close latch?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Does connector keeper lock gate properly?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
HOUSING	PASS	FAIL	NOTE
Is housing free of cracks/defects/blemishes?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Are all fasteners present/tight?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Does anchor point rotate and undamaged?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
LIFELINE	PASS	FAIL	NOTE
Is termination tight/undamaged?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Is cable free of cuts or fraying (100%)?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Does braking mechanism function per design?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Does lifeline retract properly?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Are cable strands all intact?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Is buffer spring undamaged?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Does cable show excessive wear?	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>



NOTES:

FOR MORE INFORMATION CONTACT US:

(800) 451-3077 OR VISIT WWW.RITZSAFETY.COM

